

RevitaGlow Concealer

2886-1.04



+ Fluid & light texture

+ Skincare x Makeup

+ Medium coverage

Phase	Name	INCI	Supplier	%
A	EMULIUM® ILLUSTR0	POLYGLYCERYL-6 POLYHYDROXYSTEARATE, POLYGLYCERYL-6 POLYRICINOLEATE, POLYGLYCERIN-6	GATTEFOSSE	4.50
	LEXFEEL™ NATURAL	HEPTYL UNDECYLENATE	INOLEX	5.00
	EYEGLORIUS™	OCTYLDODECYL MYRISTATE, HIPPOPHAE RHAMNOIDES EXTRACT	GATTEFOSSE	2.00
	CETIOL® CC	DICAPRYLYL CARBONATE	BASF	5.00
	LIPOCIRE™ A SG	C10-18 TRIGLYCERIDES	GATTEFOSSE	2.00
	PRESERVATIVE	PRESERVATIVE	-	1.00
B	BENTONE GEL® GTCC V	CAPRYLIC/CAPRIC TRIGLYCERIDE, STEARALKONIUM HECTORITE, PROPYLENE CARBONATE	ELEMENTIS	5.00
C	UNIPURE® WHITE LC 981 HLC	TITANIUM DIOXIDE, HYDROGENATED LECITHIN	SENSIENT	7.17
	UNIPURE® YELLOW LC 182 HLC	CI 77492, HYDROGENATED LECITHIN	SENSIENT	0.90
	UNIPURE® RED LC 381 HLC	CI 77491, HYDROGENATED LECITHIN	SENSIENT	0.15
	UNIPURE® BLACK LC 989 HLC	CI 77499, HYDROGENATED LECITHIN	SENSIENT	0.03
	LABRAFACT™ CC MB	CAPRYLIC/CAPRIC TRIGLYCERIDE	GATTEFOSSE	5.00
	EMULIUM® ILLUSTR0	POLYGLYCERYL-6 POLYHYDROXYSTEARATE, POLYGLYCERYL-6 POLYRICINOLEATE, POLYGLYCERIN-6	GATTEFOSSE	0.50
D	DEMINEALIZED WATER	WATER	-	37.75
	MAGNESIUM SULFATE (99%)	MAGNESIUM SULFATE	-	2.00
	SODIUM CHLORIDE, CODEX	SODIUM CHLORIDE	-	1.00
	PROPANEDIOL	PROPANEDIOL	-	3.00
E	CETIOL® ULTIMATE	UNDECANE, TRIDECANE	BASF	4.00
F	SERICA 5	MICA	SENSIENT	2.00
	AMIHOPE® LL	LAUROYL LYSINE	AJINOMOTO	5.00
	SILICA BEADS SB-700	SILICA	MIYOSHI	4.00
G	SYNCRYSTAL® IVORY	SYNTHETIC FLUORPHLOGOPITE, TITANIUM DIOXIDE, IRON OXIDE, TIN OXIDE	ECKART	1.00
H	GATULINE® LINK N LIFT	FRUCTOSE, GLYCERIN, WATER, AESCULUS HIPPOCASTANUM (HORSE CHESTNUT) EXTRACT	GATTEFOSSE	2.00

100.00

Operating instructions

- In the main vessel, weight and heat phase A at 40°C to melt Lipocire™ A SG.
- Add phase B and disperse with rotor stator until the phase is homogeneous.
- Prepare the pigment phase C: wet pigments with Labrafact™ CC MB and Emulium® Illustro and use a three-roll mill to get a homogeneous paste with no undispersed particles. Add it to phase A+B and disperse the pigment paste with high shear or rotor stator. Check that everything is well dispersed.
- Prepare water phase D, heat at 40°C and solubilize the electrolytes.
- Proceed with the emulsion of phase D into phase A+B+C at 40°C under medium shear, and then increase to high shear (2500/3000 rpm) for 10 minutes.
- Cool down under moderate shear and below 30°C add phase E and the powders of phase F. Mix under moderate shear for 5-10 minutes, until complete incorporation.
- Add then phases G and H one by one, under low shear and check that the final product is homogeneous.

RevitaGlow Concealer

2886-1.04



+ Fluid & light texture

+ Skincare x Makeup

+ Medium coverage

Description

Discover a natural concealer that doesn't look to be. Its light texture will care of all types of eye contour, even the driest. With its powdery radiant finish, this concealer will illuminate eye area and take care of this fragile zone through two actions: **Eyeglorius™** helps to reduce dark circles even without makeup, and **Gatuline® Link'n'Lift** targets all eye contour wrinkles.

Specifications

+ Aspect:
Liquid beige emulsion

+ Viscosity Brookfield RV (spindle A, speed 5):
approx. 16500 mPa.s after 24h

+ >97% natural origin (ISO 16128)

Ingredients

- **Emulium® Illustro** is a sensorial natural origin W/O emulsifier. In this formula, it is also used as a wetting agent in Phase C in order to better disperse the pigments, thanks to its excellent pigment compatibility. **Labrafac™ CC MB** also helps to wet pigments.
- Cetiol® Ultimate, because of its apolar nature, is poorly compatible with Emulium® Illustro. That is why it is added after emulsification.
- **Lipocire™ A SG** improves the formula's creaminess and comfort specially in the under-eye area.
- Bentone Gel® GTCC V ensures rheological control and suspension of pigments and powders.
- Unipure® HLC are hydrogenated lecithin coated pigments that have a very good affinity with W/O emulsions made with Emulium® Illustro.
- Magnesium Sulfate (99%) and Sodium Chloride are electrolytes put in aqueous phase to avoid Ostwald ripening.
- **Eyeglorius™** is an oil-soluble bioactive that corrects two eye concerns at once: dark circles and eye bags. It specifically acts on microcirculation and excessive vascular permeability induced by inflammation in the fragile sub-ocular region. It is derived from the upcycling of sea buckthorn leaves.
- **Gatuline® Link n Lift** is an extract of horse chesnut flower that targets all eye contour wrinkles, a good complementary action to **Eyeglorius™**.